



NOTES

1. BLOW OFF ASSEMBLY AND TILE TO BE SET BEHIND CURB LINE OR BACK OF SIDEWALK
2. SLOPE TUBING TO PROVIDE CONTINUOUS RISE IN PIPE FROM CORPORATION BALL VALVE TO AIR-VACUUM VALVE.

W8 AIR-VACUUM RELIEF VALVE
NTS City of Yakima – Engineering Division

APPROVED: 11.15.16