

NOTES

- 1. USE POLYETHYLENE TUBING.
- 2. WHEN USING POLYETHYLENE TUBING A BENDING SUPPORT MUST BE USED AT ALL 90° BENDS.
- 3. WHEN USING POLYETHYLENE TUBING AN INTERNAL TUBING STIFFENER MUST BE USED ON ALL FITTINGS.

W14 3/4" & 1" METER INSTALLATION

NTS City of Yakima — Engineering Division

APPROVED: 11.15.16